

## BUILD AROUND CORNER BATHS/SPAS

*Corner baths and spas are hard to be enclosed as pipes and access panels often causing problems. Access for pump maintenance is usually difficult.*

*Using Marmox boards cutting construction time considerably and finished surfaces are ready for tiling.*

### PROCEDURES

Mark the line of the bathtub allowing for tiles, boards and tile adhesive. Use **WBs** (wall brackets) to connect 30 mm boards to the walls and floor. Use silicone bead on all boards edges for waterproofing.

Cut one set of strips (30 mm boards) to suit the length of each side of the bath to the height of the step minus 50 mm. Fix one strip to the board using cement based adhesive.

Calculate the length of the other set of strips, cut them to the same high as the previous set and fix them at a distance equal to the required width of the step using **WB** (wall brackets).

Cut stiffeners to suit the step profile using 50 mm boards, insert them between the 30 mm boards at max. 300 mm spacing.

Cut the step tread to suit the profile and affix to the step stiffeners using silicone.

